


# Wiring Diagram

for connecting a *STERLING* DAR12 or PDAR advanced regulator  
to a Prestolite 110A alternator

Set Sterling advanced regulator to NEGATIVE field control!



## ***STERLING POWER PRODUCTS LTD***

86A Blackpole Trading Estate West  
Worcester, WR3 8TJ

England

Tel.: +44 (0)1905 452105

Fax: +44 (0)1905 458836

Email: [help@sterling-power.com](mailto:help@sterling-power.com)